
Basic Process - How Reactors Work

Fuel - Thermal Fission - Fission Fragments

The majority of nuclear reactors used in power plants world-wide are called thermal reactors because they use primarily thermal fission. Thermal **neutrons** (in **red** in figure below) "move in thermal equilibrium with the environment they are in." At a temperature of 550F, this corresponds to a velocity of about 3700 meters per second.

When these neutrons strike a **uranium-235 nucleus** (in **blue** in figure below) in the **Fuel**, sometimes the nucleus will split, or fission, into 2 unequally sized nuclei called **fission fragments** (in **green** in figure below). The fission products are large positively-charged particles of elements like Strontium or Iodine. These fission products slow down quickly in the fuel . They are the major contributor to heat production in the fuel (~80%). This heat gets transmitted to the coolant outside the fuel.

Also produced are between 2 and 3 neutrons (in **red** in figure below) at a very high energy. These neutrons must slow down to the thermal energy to increase the likelihood of causing further fissions.



Moderator

A **Moderator** is used to slow the neutrons down to the thermal energy. The neutrons usually do not travel very far in the reactor. They get produced from the fission in the fuel, bounce around a lot in the moderator and lose most of their energy, then cause fission (sometimes) or get absorbed in the fuel (and produce a more highly energized uranium isotope, which then decays into another material by gamma and/or beta decay).

Coolant

The purpose of the nuclear fission process is to produce heat. The fission fragments that are produced by the fission then slow down in the fuel losing most of their energy. The energy is converted to heat in the fuel. A **Coolant** is used to remove the heat and maintain the temperature of the fuel within acceptable limits. Sometimes the coolant is used to cool the moderator which, in turn, can be used to cool the fuel. Sometimes the moderator are the same material (e.g. water).

More on Fuel and Uranium Isotopes

The fuel in the reactor is in the form of pellets of either uranium metal or uranium dioxide. There are 2 or more uranium (U) isotopes (*iso* means *same; p* refers to the protons, i.e. isotopes are nuclides with the same number of protons, but different numbers of neutrons) - U-235 and U-238. U-238 is the most common form of uranium found in nature. It has 92 protons and 146 neutrons = total atomic mass number of 238. 99.27 % of uranium found in nature is U-238. The rest is U-235 (0.72%) and U-234 (0.0055%). In commercial reactors the fuel often has a higher concentration of U-235 than found in nature - typically 2 to 5%, compared to the 0.72% in nature. See the heavy water moderated reactor section for more on reactors with no enrichment. We say the fuel is *enriched* and the process used to make fuel with the higher U-235 levels is *enrichment*.

U-235 will undergo thermal and fast fission, i.e. it will *likely* fission when hit by neutrons of any energy - *but not always*; sometimes the neutron will bounce off (called scattering) and sometimes it will be absorbed by the U-235 (called absorption).



Courtesy Canadian Coalition for Nuclear Responsibility

U-238 will only undergo fission when it is struck by faster neutrons of certain energies. Sometimes it will absorb neutrons of certain energies. When it does this, the U-238 will undergo a series of decays to form Plutonium-239 (Pu-239). When this happens, the Pu-239 may also fission with thermal neutrons. In the typical commercial reactor, Pu-239 is created and fissions throughout the period of a cycle. Just before the reactor is shutdown for refueling **almost 30%** of the power generated by the reactor may be due to the Pu-239.

In Europe, some countries, e.g. France, reprocess spent nuclear fuel. The plutonium is chemically separated from the spent fuel and used with U-235 and U-238 in the preparation of new fuel to be installed in the reactor. This type of fuel is referred to as Mixed Oxide Fuel, or *MOX* for short. Originally, breeder reactors had been planned to produce the Pu-239 for use in MOX fuels in the thermal reactors. Because of plutonium proliferation concerns, the reprocessing option was disallowed in the United States. At that time, the United States tried to halt all reprocessing of spent fuel world wide, since separated plutonium could be used to make atomic bombs. There are 2 schools of thought regarding plutonium proliferation - some as World Nuclear Association, EdF, and British Nuclear Fuels advocate the use of plutonium as an energy source. Others, as the <u>Canadian Coalition for Nuclear Responsibility</u> and the <u>Nuclear Control Institute</u> feel that the production of plutonium is a serious disadvantage of nuclear power as an energy source.

Links for Related Searches

- <u>Atomic Structure Course Notes</u>
- <u>Nuclear Reactor Theory Course Notes</u>
- <u>Nuclear Fission</u> <u>Spontaneous</u> <u>Induced</u>
- <u>Fissile Material</u> <u>Fissionable Material</u> <u>Fertile Material</u>
- <u>Th-232</u> <u>U-233</u> <u>U-235</u> <u>U-238</u> <u>Pu-238</u> <u>Pu-239</u> <u>Pu-240</u> <u>Pu-241</u> <u>Pu-242</u> <u>Cf-252</u>
- <u>Mixed Oxide Fuel</u>
- <u>Neutron Flux</u> <u>Neutron Energy</u> <u>Thermal Energy</u>
- <u>Neutron Interactions</u>
- <u>Fission Products</u>
- Chart of Nuclides
- <u>Neutron Cross Section</u> <u>Neutron Capture Resonance</u> <u>Neutron Capture</u> <u>Thermal Fission</u> <u>Fast</u> <u>Fission</u>
- <u>Neutron Poisons</u> <u>I-135</u> <u>Xe-135</u> <u>Sm-149</u> <u>Ag-In-Cd</u> <u>Hf</u> <u>Boron Carbide</u> <u>Gadolinium</u>
- <u>Control Rods</u>
- <u>Mass Yield Curve</u>

Copyright © 1996-2008. The Virtual Nuclear Tourist. All rights reserved. Revised: November 3, 2008.